

88 5181 35

Arts & Crafts Bistro Table


Black Finish

IMPORTANT NOTE


Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occurring to the wood parts.

We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.

*Home
Styles*



Part List




A.
Top
1 pc.



B.
Leg
4 pcs.

Hardware List




Key Wrench
1 pc.



Spring Washer
8 pcs. (+1 extra)



Flat Washer
8 pcs. (+1 extra)



Bolt
8 pcs. (+1 extra)

Assembly Instructions 2/2

IMPORTANT

- * Do not tighten up all the bolts until each part is properly assembled.
- * You should keep Key Wrench in a safe place as you may need to tighten up the Bolts in the future.





Figure 1



STEP 1

Turn Top (A) upside down and place on a soft cloth.
Attach Legs (B) to Top (A) with Flat Washers, Spring Washers and Bolts (see Figure 1).
Turn the table over to its' upright position.