

88 5543 181

Bermuda Pedestal Desk

IMPORTANT NOTE


Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damage occurring to the parts.

We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.

Home
Styles



Part List




A.
Top
1 Pc.




J.
Shelf
1 Pc.



M.
Keyboard Rail
2 Pcs.




K.
Keyboard Front
1 Pc.



L.
Keyboard
1 Pc.

(Knock-Down Construction,
please refer to the last page of 88 5542 182
instruction for keyboard assembly steps.)



N.
Keyboard Support
1 Pc.



O.
Keyboard Support
1 Pc.




P.
Keyboard Support
1 Pc.



I.
Back Panel
1 Pc.

Hardware List




Hex Wrench
1 Pc.




Cam Lock Screw
46 Pcs. (+2 extra)



Wood Screw (long)
For side drawer
47 Pcs. (+1 extra)



Magnet
1 Pc.



Adjustable Pin
4 Pcs. (+1 extra)



Pull Handle
7 Pcs.



Small Hex Wrench
1 Pc.



Cam Lock
46 Pcs. (+6 extra)



Wood Screw (short)
For drawer base
16 Pcs. (+1 extra)



Wood Screw
For Hinge
6 Pcs. (+1 extra)



Wood Screw
For Magnet
2 Pcs. (+1 extra)



Head Cap Bolt
4 Pcs. (+1 extra)



Machine Screw
7 Pcs.

For assembly see instructions in carton 88 5542 182

Tools required for assembly : Phillips screwdriver

Home Styles Consumer Assistance: www.homestyles-furniture.com,
servicedesk@homestyles-furniture.com, 888-680-7460, 877-831-0319