


# 88 5548 00 Marco Island Media Hutch

## IMPORTANT NOTE

Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damage occurring to the parts.


We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.

Home  
Styles



## Part List


A.  
Top  
1 pc.




D.  
Front Rail  
1 pc.




B.  
Side Panel  
1 pc.




C.  
Side Panel  
1 pc.




E.  
Back Panel  
1 pc.



## Hardware List



1 1/4" Flat Head Screw  
4 pcs.(+ 1 extra)



Cam Lock Screw  
8 pcs.(+ 1 extra)



Cam Lock  
8 pcs.(+ 1 extra)

Tools required for assembly: Phillips screwdriver

**Home Styles Consumer Assistance :** [www.homestyles-furniture.com](http://www.homestyles-furniture.com),  
[servicedesk@homestyles-furniture.com](mailto:servicedesk@homestyles-furniture.com), 888-680-7460, 877-831-0319


## Assembly Instructions 2/4

### IMPORTANT

- \* Do not tighten up all the screws until each part is properly assembled.
- \* After assembly, item must be level to work properly. Use the included adjustable levelers to level.
- \* Use a soft cloth between these part and the floor.

### STEP 1

Insert Cam Lock Screws into the pre-drilled holes of Top (A) Side Panels (B) and (C).



### STEP 2

Attach Front Rail (D) to Top (A) with 1 1/4" Flat Head Screws. (See Figure 1)






Figure 1

## Assembly Instructions 3/4


### STEP 3

Attach Back Panel (E) to unit with Cam Locks.  
(See Figure 2)




### STEP 4

Attach Side Panels (B) and (C) to unit with Cam Locks.  
(See Figure 3)



## Assembly Instructions 4/4



### STEP 5

Place unit on top of  
Marco Island Chest (Carton 88 5548 41).