


88 5570 95112 Kitchen Cart

IMPORTANT NOTE




Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occurring to the wood parts.

We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.


*Home
Styles*



Part List



Hardware List



Also need Top (A) from top carton

Tools required for assembly : Phillips screwdriver

Home Styles Consumer Assistance: www.homestyles-furniture.com,
servicedesk@homestyles-furniture.com, 888-680-7460, 877-831-0319

Assembly Instruction 2 / 3

IMPORTANT

* Do not tighten up all the bolts until each part is properly assembled.

* You should keep Key Wrenches and Hex Wrench in a safe place as you may need to tighten up the Nuts and Head Cap Bolts in the future.

* Use a soft cloth between these parts and the floor.

STEP 1

Attach Legs (D) to Top Frame (B) with Head Cap Bolts.
(see Figure 1)

Attach Shelves (C) to unit with Head Cap Bolts.






Figure 1



STEP 2

Attach Legs (D) to unit with Head Cap Bolts.

STEP 3

Attach Casters to unit with Washers, Spring Washers and Nuts.
(see figure 2)





Figure 2

STEP 4

Turn unit over to its' upright position.

Attach Side Bars (E) to unit with Small Nuts. (see figure 3)

Attach Top (A) to unit with Head Cap Bolts.




Figure 3