


# 88 5982 35C Pub Table

## IMPORTANT NOTE


Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occurring to the parts.

We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.



*Home Styles*




## PART LIST



## HARDWARE LIST



## Leg Assembly Details



## Leg Assembly

Turn over the Table Top (A) and place on the soft material.

Assemble the legs (B) with Bolts, Spring Washers and Flat Washers.

Attach the Stretcher (C) and (D) to the four legs, using Wood Screws.

Turn back the table to its normal position.

Please keep the Key Wrench as you may need to retighten the Bolts in the future.

Tools required for assembly : **Phillips** screwdriver

Tools recommended for assembly : Level

**Home Styles Consumer Assistance Line 888-680-7460 and 877-831-0319**

**[servicedesk@homestyles-furniture.com](mailto:servicedesk@homestyles-furniture.com)**

Revised date : 04Mar2011


# 88 5983 35C Pub Table

## IMPORTANT NOTE


Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occurring to the parts.

We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.



*Home Styles*




## PART LIST



## HARDWARE LIST



## Leg Assembly Details



## Leg Assembly

Turn over the Table Top (A) and place on the soft material.

Assemble the legs (B) with Bolts, Spring Washers and Flat Washers.

Attach the Stretcher (C) and (D) to the four legs, using Wood Screws.

Turn back the table to its normal position.

Please keep the Key Wrench as you may need to retighten the Bolts in the future.

Tools required for assembly : **Phillips** screwdriver

Tools recommended for assembly : Level

**Home Styles Consumer Assistance Line 888-680-7460 and 877-831-0319**

**[servicedesk@homestyles-furniture.com](mailto:servicedesk@homestyles-furniture.com)**

**Revised date : 03Mar2011**


# 88 5986 35C Pub Table

## IMPORTANT NOTE


Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occurring to the parts.

We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.



*Home Styles*




## PART LIST



## HARDWARE LIST



## Leg Assembly Details



## Leg Assembly

Turn over the Table Top (A) and place on the soft material.

Assemble the legs (B) with Bolts, Spring Washers and Flat Washers.

Attach the Stretcher (C) and (D) to the four legs, using Wood Screws.

Turn back the table to its normal position.

Please keep the Key Wrench as you may need to retighten the Bolts in the future.

Tools required for assembly : **Phillips** screwdriver

Tools recommended for assembly : Level

**Home Styles Consumer Assistance Line 888-680-7460 and 877-831-0319**

**[servicedesk@homestyles-furniture.com](mailto:servicedesk@homestyles-furniture.com)**

Revised date : 03Mar2011