

homestyles[®]

88 5530 911 Storage Island




IMPORTANT

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.

Part List



A.
Top
1 pc.


For assembly see instructions in carton 88 5530 912.

Home Styles Customer Service: www.homestyles-furniture.com,
servicedesk@homestyles-furniture.com, 888-680-7460, 877-831-0319

Unpacking Instructions

STEP 1

Open carton.



STEP 2

Use a hammer to remove the 3x inner upper wood supports. (see Figure 1)





Figure 1

STEP 3

Remove foam and Top (A).

