


88 5134 307 Hutch

IMPORTANT NOTE


Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occurring to the wood parts.

We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.

*Home
Styles*




Part List



A.
Top
1 pc.



B.
Side Panel
1 pc.



C.
Side Panel
1 pc.




D.
Front Rail
1 pc.




E.
Back Stretcher
1 pc.




F.
Back Stretcher
1 pc.




G.
Shelf
1 pc.




H.
Divider
1 pc.



I.
Back Panel
2 pcs.




J.
Back Panel
1 pc.




K.
Shelf
2 pcs.

Hardware List



Hex Wrench
1 pc.



Small Wrench
1 pc.




M6x15
Head Cap Bolt (short)
4 pcs.(+1 extra)



M6x30
Head Cap Bolt
26 pcs.(+1 extra)



Adjustable Pin
8 pcs.(+1 extra)



Steel Plate
2 pcs.

Tools required for assembly : Drill, 3/8" Drill Bit

Home Styles Consumer Assistance: www.homestyles-furniture.com,
servicedesk@homestyles-furniture.com, 888-680-7460, 877-831-0319

Assembly Instructions 2/5

IMPORTANT

**Please keep Hex Wrench in a safe place as you may need to tighten up the Head Cap Bolts in the future.*

**Do not tighten up all the Head Cap Bolts until each part is properly assembled.*

**Use a soft cloth between these parts and the floor.*

STEP 1

Attach Back Stretcher (E) and Shelf (F) to Side Panel (B) with Head Cap Bolts, tightening the bolts only half way.
(See Figure 1)






Figure 1



STEP 2

Attach Front Rail (D) and Side Panel (C) to unit with Head Cap Bolts, tightening the bolts only half way.



Tighten all Head Cap Bolts used in Steps 1 and 2.

STEP 3

Turn unit to its' upright position.

Attach Divider (G) to unit with Head Cap Bolts.

Slide Back Panels (H) and (I) into position.



STEP 4

Attach Back Stretcher (F) to unit with Head Cap Bolts.



Insert Head Cap Bolts into the pre-drilled holes of back panels.

STEP 5

Attach Top (A) to unit with Head Cap Bolts.

Insert Adjustable Pins into side panels at the desired level.

Place Shelves (K) into position.



STEP 6

Attach Hutch to Buffet with Steel Plates and Head Cap Bolts (short).

Attention!

To help reduce the risk of the unit tipping over, the Tipover Restraint must be installed following these instructions exactly!

Place unit at desired location.

Drill a 3/8" hole in wall at the appropriate location.

Insert Anchor into the wall hole and attach Bracket with Wall Screw.

Attach Bracket at pre-drilled hole at top of unit with Wood Screw.

Use Tipover Restraint to secure Bracket on unit to Bracket on wall.
(See Figure X)

Put tie end of Tipover Restraint into loop end of Tipover Restraint and pull until tight.







Figure X




Hardware List




Anchor
1 pc.(+1 extra)



Bracket
2 pcs.(+1 extra)



Tipover Restraint
1 pc.(+1 extra)



**M3.5x40
Wall Screw**
1 pc.(+1 extra)



**M3.5x16
Wood Screw**
1 pc.(+1 extra)